## Scan 66 series



## Congratulations on your new Scan wood-burning stove

You have purchased a product by one of Europe's leading manufacturer's of wood-burning stoves, and we are sure that you will have years of pleasure with your purchase. To make the best possible use of your stove, it is important that you follow our advice and instructions.

Please read this Assembly- and instructions manual before you start to assemble your stove.

Product registration number

Please indicate the product registration number at any enquiry

SCAN

## SCAN A/S - DK-5492 VISSENBJERG

## Table of contents

Technical data
Installation
Safety
Technical data and dimensions
Dimension sketches
Type plate
Product registration number
Assembly10
Additional accessories
Loose parts
Disposal of packaging
Mounting of the base/wall fitting
Mounting of the burn chamber
Positioning your wood-burning stove
Distance to furniture
Distance to flammable materials, shown with insulated flue pipe
Distance to flammable materials, shown with un-insulated flue pipe
Distance to firewall
Height adjustment of stove
Load bearing foundation
Floor plate
Existing chimney and pre-fabricated element chimney
Connection between stove and steel chimney
Requirements for chimney
Connection with 90° elbow pipe
Connecting piece / top outlet
Connecting piece / rear outlet
Freshair intake
Closed combustion system
Instruction for heating
CB technique
Primary air
Secondary air
Baffle plates
Ash drawer
Log guard
Lighting
Handling fuel
Maintenance
Troubleshooting

#### Installation

The house owner is responsible for ensuring that installation and assembly are in accordance with national and local building regulations as well as the information provided in this Assembly and Instruction Manual.

When you install any kind of fireplace or stove, you must inform the local building and housing authorities. In addition you are obliged to have the installation inspected and approved by a local chimney sweep prior to commissioning.

To ensure best-possible functionality and safety for your installation, we advise you to call a professional fitter. Your Scan Dealer will be able to recommend a qualified fitter in your area. For information on Scan Dealers, please go to http:// scan.dk.

#### Safety

Any changes made to the product by the dealer, fitter or user could result in the product and safety functions not functioning as intended. The same applies to the fitting of accessories or extra equipment not supplied by Scan A/S. This could also be the case if parts that are necessary for the operation and safety of the stove are dismantled or removed.

#### The Scan 66-series consists of:



Scan 66-1 Wallmodell



Scan 66-2 With pedestal base



Scan 66-4 With plinth base



Scan 66-5 With S-Curve base

#### Technical data and dimensions

Materials	Steel plate, cast iron, galvani- sed sheet, vermicolite
Surface treatment	Senotherm
Max. wood length	33 cm
Weight	ca. 90-108 kg
Connecting piece internal diameter	144 mm
Connecting piece external diameter	148 mm
Approval type	Intermittent fuelling

PLEASE NOTE: You get the best use of the stove by using a "top-down lighting", see page 28.

Intermittent operation in this context means normal use of a woodburning stove. In other words, you should let the fire die down until only the embers are left before refueling.

This stove is produced in accordance with type approval for the product, which also covers the product's Assembly and Instruction Manual.

The Declaration of Performance (DoP) is available from www.scan.dk

#### Test in compliance with EN 13240

Scan 66	Technical data	Unit
CO Emission at 13% O <sub>2</sub>	0,029	%
CO Emission at 13% O2	367	mg/Nm <sup>3</sup>
Dust @ 13% O <sub>2</sub>	27	mg/Nm <sup>3</sup>
No <sub>x</sub> @ 13% O <sub>2</sub>	85	mg/Nm <sup>3</sup>
Efficiency	78	%
Energy efficiency index	104,1	
Energy efficiency class	А	
Nominel output	5	kW
Chimney temperature EN 13240	302	°C
Amount of smoke	5,0	g/sek
Sub-pressure EN 13240	12	Pa
Recommended sub-pressure in connecting piece	16 - 18	Pa
Required combustion air supply	10,2	m <sup>3</sup> /h
Fuel		Wood
Fuel consumption	1,72	kg/h
Amount of fuel	1,3	kg

#### Dimension sketch Scan 66-1 Wall









Centre rear outlet

\*

- \*\* Height to the beginning of the connecting piece at top outlet
- \*\*\* Fresh air intake at the back of the stove
- \*\*\*\* Centre of fresh air intake bottom/ Connecting piece top outlet

#### Dimension sketch Scan 66-2 Pedestal



- \* Centre rear outlet
- \*\* Height to the beginning of the connecting piece at top outlet
- \*\*\* Fresh air intake at the back of the stove
- \*\*\*\* Centre of fresh air intake bottom/ Connecting piece top outlet

### Dimension sketch Scan 66-4 Plinth







- \* Centre rear outlet
- \*\* Height to the beginning of the connecting piece at top outlet
- \*\*\* Fresh air intake at the back of the stove
- \*\*\*\* Centre of fresh air intake bottom/ Connecting piece top outlet

## TECHNICAL DATA

## Dimension sketch Scan 66-5 S-Curve



## TECHNICAL DATA

#### Type plate

All Scan wood-burning stoves are fitted with a type plate that specifies the approval standards and the distance to flammable materials.

The type plate is located at the rear of the stove.



#### **Product registration number**

All Scan wood-burning stoves are provided with a product registration number.

The product registration number is located at the rear of the stove.

Please make a note of this number at the frontpage; you will always need to quote it when contacting your dealer or Scan A/S.

Product:					
Scan 6	6-1 - 66-2	- 66-4 - 66-	5 CE 14		
Freestan	ling room heat	ter fired by solid	fuel DoP: 9006660		
Standard:	EN 13240:2001/A	2:2004:AC: 2007			
Minimum o Side: 300 m	listance to adjace ım - Back: 150 mn	nt combustible mat n - Front: 850 mm	erials:		
Side: 300 mm - Back: 150 mm - Front: 850 mm Emission of CO in combustion products (13% O) 2 : 367 mg/Nm3 Emission of NOx in combustion products (13% O) 2 : 85 mg/Nm3 Emission of OGC in combustion products (13% O) 2 : 27 mg/Nm3 Emission of PM in combustion products (13% O) 2 : 27 mg/Nm3 Flue gas temperature : 302 °C Nominal heat output : 5 kW Efficiency : 78 % Fuel type : Wood Operation type : Intermittent Reaction to fire : A1 Electrical safety :- The appliance can be used in a shared flue Approved by: DTI, NB.no 1235 Follow user's instructions. Use only recommended fuels. Montage- und Bedien ungsanleitung beachten.					
Verwender Respectez	Sie nur empfoh es consignes d'u	lenen Brennstoffer tlisation. Utilisez u	n. niquement		
Manufac	turer: Scan A	S - DK 5492 Viss	enbjerg		
			12055829 9005		
Country	Classification	Standard	Approved by		
EUR	Intermittent	EN 13240	DTI, NB.no 1235		
NORWAY	Klasse 2	NS 3058	DTI, NB.no 1235		
SCHWEIZ		VKF, No. 25728	DTI, NB.no 1235		
	An official states in the	the hole strong to reaching a			

Lot no: 000000 2019

Pin:000

Product registration number

#### Additional accessories

- Small shaped floor plate in glass or steel (steel only 66-2 & 66-5)
- Large shaped floor plate in glass or steel (steel only 66-2 & 66-5)

#### Loose parts

- Glove
- Gasket
- Repair lacquer for colored stoves

#### Disposal of packaging

Your Scan stove may come supplied with the following packaging:

**WOOD PACKAGING:** The wood packaging can be reused and after final use can be incinerated as a CO2 neutral product or sent for recycling.

**POLYSTYRENE TOP:** Send for recycling or waste disposal.

FOAM: Send for recycling or waste disposal.

**PLASTIC BAGS:** Send for recycling or waste disposal.

STRETCH FILM/PLASTIC FILM: Send for recycling or waste disposal.

#### Mounting of the base/wall fitting

Mount the base/the wall fitting before removing the stove from the packaging.

Scan 66-1





#### Please note!

The stove must remain in the packaging during the mounting of the wall fitting at top outlet.

If the stove is to be connected with a rear outlet, the stove must be lifted out of the packaging and laid on e.g. a carpet, the front facing downwards. See page 25.





The bag contains:



#### PLEASE NOTE!

In order to mount the wall fitting to a chimney made of Leca-blocks you need 6 pcs. FBS 8x70/5 US Leca screws.

The test report can be required at Scan A/S.





## A S S E M B L Y



Remove the slits - use a drilling machine and nippers.



Dismount the rear plate by removing the four screws. Place the rear plate on an even surface.



Mount the rear plate loosely; it is not to be fixed, until after the wall fitting has been mounted.





Mount the bottom plate on the existing four screws.

Mount the four screws loosely in the rear plate again, now with the wall fitting in between. Screw the rails and the bottom plate together in the sides. Tighten the four bottom screws. Tighten up all screws.

Let the rails glide down through the hole along the bottom plate.



Mount the two adjustment screws.









Mount the screws in order to lock the stove to the wall fitting.



Now hook the stove onto the wall fitting on the wall.

Adjust the stove so that the doors has the correct slope.



#### External combustion air from the bottom

Use the delivered division plate. First cut out the hole, mount the division plate, then the pedestal. Fasten the screws.

(see page 26)



#### No external combustion air

Mount the pedestal directly on the stove, without the division plate.



**External combustion air from the rear** Mount the delivered cover plate, then the pedestal.

The cover plate from the rear is not to be reused.

Fasten the screws.



### Scan 66-4



Fasten the four screws after mounting the base.



Prepared for external air at the bottom.

Cut out the hole with a pair of cutting nippers.

Scan 66 -5



Loosen the four screws (ca. 4-5 mm) so that it is possible to hook the base on the stove.

Place the delivered magnets on the markings on the front of the base and mount the loose front. Please note that the base can be mounted at the right or at the left of the stove.

Fasten the screws lightly so that it is possible to lift the stove with

Make sure that the S-base is horizontal – if necessary, use a spirit level. Adjust the stove on the base, and then tighten the four screws.

## A S S E M B LY













#### Opening of the door Push the handle backwards in order to open the door.





Close the door without moving the handle.



## A S S E M B L Y



Please remove protection



Mount the rear plate



Slide the plate behind the grate



Rear plate mounted



Fit the left side plate in at the top



Slide the plate in place



Left side plate mounted



Mount the right side plate in the same way as the left plate



Right side plate mounted



Upper front plate



Pass the plate towards the rear



Lift the plate over the side plates

## A S S E M B L Y



Let the plate glide back on the upper edge



Upper baffle



Mount the upper baffle (the carvings must turn backwards)



Push the plate upwards so that it rests on the front plate



Push the plate a bit backwards so that it rests on the rail in the back



Lower baffle



Let the plate rest on the rail with the air slots



Push the plate backwards in order to mount the pins



Mount the pins in the side plates



All burn chamber plates have now been mounted



Mount the glass log guard



The stove can now be taken into use

#### Positioning your wood-burning stove

There are no requirements concerning the distance to non-combustible materials, but we recommend a distance of 50 mm in order to facilitate the cleaning of the stove, the flue pipe and the chimney, and to prevent possible damages to the wall.

#### Distance to furniture: 850 mm

You should however assess whether furniture or other items might become excessively dry due to being too close to the stove.

National and local regulations governing safety distances for wood-burning stoves must be complied with.

If the stove is to be connected to a steel chimney, the chimney requirements in terms of safety distances must be met.

#### **Distance to flammable materials**

These distances apply for an uninsulated flue pipe/insulated flue pipe, all the way down to the stove, having a minimum of 30 mm insulation.

#### Wall model

Distance from the floor to the stove

The wall model is only to be mounted on a non-combustible wall.





#### Wood Storage

Scan 66-5 S-Curve is approved for wood storage on condition that the following is respected:

The wood must be placed min. 100 mm from the stove and is not to be stapled higher than to the lower edge of the handle.





#### Distance to flammable materials, shown with insulated flue pipe



45° Corner installation

Parallel rear wall installation

## Distance to flammable materials, shown with insulated flue pipe

The distances presuppose the use of an insulated flue pipe all the way to the stove.





45° Corner installation

Parallel rear wall installation

## Distance to firewall

The indicated distances are valid for insulated as well as un-insulated smoke pipes.









Flammable material

#### Height adjustment of stove

The stove has four adjustment screws under the stove. Use the adjustment screws to get the stove to stand straight and level.

\*To adjust the adjustment screws, see the illustrations below.





Adjustment screw



#### Load-bearing foundation

All items in our product range come under the category of lightweight fireplaces and stoves and do not normally require any reinforcement of the beam structure. They can be positioned on ordinary beams/floor.

You should of course make sure that the foundation on which the stove is positioned can indeed support the weight of the stove and, where applicable, a steel chimney, if you have opted for this solution. In case of doubt about the carrying capacity of the floor, please consult a building expert.

#### Floor plate

If you are placing the stove on a flammable floor, you must comply with the national and local regulations on the size of any non-flammable foundation required to cover the floor around the stove.

Your local Scan dealer can advise you on regulations concerning protection of flammable materials in the vicinity of your stove.

The floor plate's function is to protect the floor and flammable material against any sparks that may occur. A floor plate can be made of steel or glass, but the stove can also be placed on quarry tiles, concrete, natural stone or similar materials.

This Scan wood-burning stove has an integrated floor plate at the bottom and can thus be placed directly on flammable materials without the need for further protection underneath the stove.

#### Large shaped floor plate in glass or steel (Scan 66-2 Pedestal)



Small shaped floor plate in glass or steel (Scan 66-2 Pedestal)



#### Existing chimney and pre-fabricated element chimney

If you intend to connect your stove to an existing chimney, it makes sense to contact an authorised Scan dealer, or a local chimney sweep, for advice. These experts will also let you know if your chimney needs renovating.

When connecting a pre-fabricated element chimney, follow the manufacturer's connection instructions for the relevant chimney type.

#### **Connection between stove and steel chimney**

Your Scan dealer, or local chimney sweep, can advise you on choosing a make and type of steel chimney (we recommend using JØTUL's chimney system). This ensures that the chimney will match your wood-burning stove. As a general rule, the length of the chimney should not be less than 4 metres, measured from the top of the stove.

Specific weather or installation conditions might require a different length.

Choosing the wrong length or diameter of steel chimney could impair functionality.

Always observe the chimney vendor's instructions precisely.

#### **Requirements for chimney**

The chimney must be labelled T400 and G for soot testing.

#### **Connection with 90° elbow pipe**

If you opt to connect the stove with an elbow pipe, you should use a curved elbow, as this gives a better draught.

#### **Connecting piece / top outlet**

The stove is prepared from the factory for top outlet.

The connecting piece is placed loosely in the top outlet of the stove.

The gasket for the connecting piece and the screws for fastening the connecting piece are in the stove's ash drawer.







## A S S E M B L Y

Top outlet

**Rear outlet** 









## ASSEMBLY

#### Fresh air intake

In a well-insulated house the air used for the combustion process has to be replaced. This particularly applies to houses with mechanical ventilation. There are different ways of making sure that air is exchanged. The most important thing is to ensure that there is a supply of air to the room where the wood stove is located. The external wall vent must be located as close to the wood stove as possible, and you must be able to close it when you are not using the stove.

National and local building regulations must be followed with regard to connection of a fresh air intake.

#### **Closed combustion system**

You should use the closed combustion system for the wood-burning stove if you live in a newly-built, airtight home. External combustion air is connected through a ventilation pipe via the wall or floor.

We recommend mounting a valve in the ventilation pipe in order to avoid condensate in the stove and the pipe system, which can be closed when the oven is not in use. It can also be an advantage to insulate the ventilation pipe.

Minimum  $\phi$  100 mm ventilation pipe, maximum length: 6 metres with a maximum of one bend. We recommend smooth steel pipes.

If you want external combustion air via a wall, remove the cover plate at the rear of the stove with a pair of cutting pliers. See the procedure in this manual.

If the external combustion air is connected at the rear, the dismounted plate must be mounted on the hole for external air in the bottom of the stove.

**NOTE:** if the stove has a fresh air connection or closed combustion, the ventilation pipe must be open, when the stove is in use.



2.



2.





3.







#### Fuel overloading

The maximum amount of fuel specified in this manual should not be exceeded, overloading can cause excess smoke.

#### Operation with door left open

Operation with the door open can cause excess smoke. The appliance must not be operated with the appliance door left open except as directed in the instructions.

#### Dampers left open

Operation with the air controls or appliance dampers open can cause excess smoke. The appliance must not be operated with air controls, appliance dampers or door left open except as directed in the instructions.



#### **CB-technique (Clean Burning)**

The wood-burning stove is equipped with CB technology. In order to ensure an optimal combustion of released gases under the incineration process, air will pass through a specially developed canal system. The heated air is led into the combustion chamber through the small holes at the rear of the burn chamber. This airflow is driven by the combustion rate and thus cannot be regulated.

Note: Wood must never be added above the CB rail. (This does not apply at a cold start).

#### Primary air

The primary air regulation mechanism is used for lighting the fire, or to boost the burning process when you put wood on. The primary air vent can be o - 30% open if you use hard wood fuel such as oak and beech. You can close the primary air vent if you use soft wood such as birch or pine for fuel.

Settings for normal load: 0 - 30%

#### Secondary air

Secondary air is pre-heated and fed indirectly to the fire. At the same time, the secondary airflow cleans the glass pane to avoid soot buildup. If you over-restrict the secondary airflow, soot can build up on the glass pane. The secondary airflow determines the heat output from your wood stove.

#### Settings for normal load: 50 - 70%

#### **Baffle plates**

The baffle plates are located in the upper part of the combustion chamber. The plates hold back smoke, making sure it stays inside the combustion chamber for a longer time before escaping through the chimney. This reduces the smoke gas temperature as the gases have more time to dissipate heat to the wood-burning stove. The baffle plates must be removed for sweeping; see "Maintaining your wood-burning stove". Note that the baffle plates are made of porous, ceramic material, and can break. Exercise care when working. The baffle plates are subject to wear and tear, and are not covered by the warranty.

#### Ash drawer

Open the glass door to access the ash pan which is located below the combustion chamber.

Keep the ash pan closed at all times when the wood stove is lit. The ash drawer must not be overfilled and must therefore be emptied at regular intervals.

#### Log guard

The stove has a thick glass log guard that is easy to take out for cleaning (use normal glass cleaner).



#### **Environmentally-Friendly Heating**

Avoid restricting your wood-burning stove to an extent where no flames are visible during the degasifying period, as this leads to particularly inefficient heating. The gases released by the wood do not burn due to the low temperature in the combustion chamber. Part of the gas condenses in the wood-burning stove and flue system as soot, and this could lead to your chimney catching fire. The smoke that exits the chimney is bad for the environment and has an unpleasant smell.

#### Lighting

We recommend the use of fire starters, or similar products, which are available from your Scan dealer. Using fire starters helps to light the wood quicker, and keeps the burning process clean. Never use liquid lighting fuels!

#### "Top down" lighting

Important! Always use a top-down lighting. The stove is constructed for this in order to give the best exploitation."Top down" lighting is a more environmentally friendly way of lighting the fire and helps to keep the glass area as clean as possible.

2 pieces of wood approx. 20-25 cm long with a weight of approx. 0.5–0.6 kg per piece (image 1)  $\,$ 

The wood must not cover the bottom entirely and must never be placed higher than the Clean-Burn rail at the rear of the stove.

1 pieces of wood approx. 0.3–0.4 kg (image 2) 8-12 thin sticks of about 20 cm with a total weight of approx. 0,5 kg (image 3-5).3 fire starters. Place logs, sticks and fire starters in the combustion chamber as shown on images 1-5.

Set the primary and secondary air controls to maximum in the lighting phase. If the fire is too strong, you may throttle down the primary air damper (at the left).

1.



2.





4.







#### **Continuous firing**

It is important to reach as high a temperature as possible in the combustion chamber. This makes the most efficient use of the wood stove and fuel, and ensures a clean burning process. At the same time, this avoids soot build-up on the combustion chamber walls and glass. While the stove is lit, you should not see any smoke, but just air movement that indicates the burning process.

After completing the lighting phase, you should have a good layer of embers in the wood stove; you can then start stoking up the stove. Lay 1-3 pieces of wood, of about max 1,7 kg weight with max 10 cm diameter and a length of about 25 cm onto the fire.

Note! The wood must catch fire quickly; this is why we recommend setting the primary airflow to full power. Running the stove at too low a temperature and with too little primary air can lead to deflagration of the gases, and thus cause damage to the stove.

When stoking up with wood, always open the glass door carefully to avoid smoke escaping. Never stoke up with wood while the fire is still burning nicely.

#### Using your stove in the spring or autumn

In the transition period (spring/autumn), where there is less need for heating, we recommend to make a single "top down" lighting, perhaps with one stoke up to ensure that the combustion chamber lining burns clean again.

#### Why you need a chimney

The chimney is the wood-burning stove's motor; it's performance decides how well your stove will work. The draft in the chimney creates a vacuum in the wood-burning stove. The vacuum draws the smoke out of the stove, and takes in air through the combustion air baffle to fuel the burning process. Combustion air is also used for the airwash system that keeps the window clear of soot.

The draft in the chimney is caused by the difference in temperatures inside and outside the chimney. The higher the temperature difference is, the better the draft in the chimney will be. It is thus important for the chimney to reach operating temperature before you adjust the damper to restrict combustion in the stove (a brickwork chimney will take longer to reach operating temperature than a steel chimney). It is very important to reach operating temperature as quickly as possible on days on which the draft in the chimney is poor due to unfavorable wind and weather conditions. Make sure the fuel ignites as quickly as possible (with visible flames). Chop the wood into particularly small pieces; use an extra fire lighter etc.

After longer periods of disuse, check the chimney flue for blockage. You can connect several units to the same chimney. But make sure check with your chimney sweep to observe local regulations.

No matter how good your chimney is, it will not perform well if you do not use it correctly. On the other hand a poor chimney, may give you acceptable results if you use it correctly.

#### Using your stove in various weather conditions

Wind blowing on the chimney can have a great effect on how your stove reacts in various wind conditions; you may need to adjust the airflow to achieve good burning results. Fitting a damper in the flue pipe may also help as it will give you the ability to regulate the draught in changing wind conditions.

Fog can also have a great influence on how well a chimney draws; you may again need to adjust the airflow settings to achieve good burning results.

#### **General Notes**

Please note! Parts of the wood-burning stove, especially the outer surfaces, become hot during use. Please exercise due care.

Never empty ashes into a flammable container. Ashes can contain glowing embers long after you finish using your wood stove.

While the stove is not in use you can close the valves to avoid draught through the stove.

After longer breaks you should check the smoke outlet paths for blockages before lighting.

#### **Chimney fires**

In case of a chimney fire, keep the stove door, the ash container, and the valves on the stove closed. In case of emergency, call the fire service.

It is recommended that you get a chimney sweep to check the chimney before using the stove again.

## Handling fuel

#### Selecting Wood/Fuel

You can use any type of wood as firewood, however, harder types, such as beech, ash, are generally better for heating as they burn more evenly and create less ash. Other wood types like maple, birch and spruce are excellent alternatives.

#### Handling

Firewood is best if you fell the tree, and saw and split the wood, before May 1st. Remember to cut the logs to match the size of your wood-burning stove's combustion chamber. We recommend a diameter of 6-10 cm. The length should be about 6 cm shorter than that of the combustion chamber to leave enough space for air to circulate. Firewood with a greater diameter needs splitting. Split wood dries faster.

#### Storing

You need to store the sawn and split firewood in a dry place for 1-2 years before burning. Wood dries faster if you stack it in an airy place. Before use, store the firewood for a few days at room temperature. Note that wood absorbs moisture during the autumn and winter seasons.

#### Moisture

To avoid environmental issues, and for optimum burning, wood has to be perfectly dry to be suitable for use as firewood. The max. residual moisture in the wood should not exceed 20%. A moisture content of 15-18% yields best results. As an easy way of checking if wood is dry, just knock two pieces of wood together. If the wood is moist, the sound will be dull.

If you use damp wood, most of the heat it produces will be used to evaporate the water. The temperature in the wood stove does not rise, and the room is not sufficiently heated. Of course, this is not economical, and it will cause soot build up on the glass pane, in the stove, and in the chimney. Burning moist wood also causes pollution.

#### Understanding units for measuring wood

Various units of measurement are used for wood. Before you buy wood, it makes sense to familiarise yourself with the terms. There are various brochures, in public libraries for example, that cover this topic.

#### Use of the following as fuel is illegal

Painted, pressure impregnated, or glued wood, driftwood from the sea. Never burn chipboard, plastics, or chemically treated paper. These materials are dangerous to humans, to the environment, your wood stove, and your chimney. To keep a long story short – make sure you burn only quality firewood.

#### Firewood fuel value

The fuel value is different for different types of wood. In other words, you need to use more wood of certain types to achieve the same heating performance. This Instruction Manual assumes that you will be using beech, which has a very high fuel value, and is also a wood that is easy to procure. If you use oak or beech wood fuel, note that these wood types have a greater fuel value than, say, birch. Make sure you use less fuel to avoid damage to the wood-burning stove.

Wood types	Kg Dry wood/m <sup>3</sup>	Compared beech	to
Hornbeam	640	1 1 0	%
Beech/Oak	580	100	%
Ash	570	98	%
Maple	540	93	%
Birch	510	8 8	%
Pine	480	83	%
Fir	390	67	%
Poplar	380	65%	

# Maintaining your wood-burning stove

Apart from regular chimney sweeping, your wood-burning stove does not require any regular maintenance. However, we recommend servicing at least once every two years

Use only original replacement parts for maintenance and repairs of your stove.

Note! Make sure the wood-burning stove is cold before starting maintenance or repair work.

#### **Coated surfaces**

Clean your wood-burning stove by dusting with a dry, lint-free cloth. If the topcoat is damaged, you can purchase a repair spray from your authorised Scan dealer. As slight differences in colour are possible, spray a larger area to achieve a natural transition for best results. For best results, apply repair spray when the wood-burning stove is hand-hot.

#### **Cleaning the glass**

Our wood-burning stoves are designed to prevent serious soot build up on the glass. The best way to achieve this is to make sure you have a sufficient combustion air supply. It is also important to use dry wood, and have a correctly dimensioned chimney.

Even if you follow all of our instructions, a slight film of soot can build up on the glass. You can easily remove this build up by cleaning with a dry cloth and glass cleaner. Please note that the glass cleaner is not to get into contact with the gaskets, as this can discolour the glass permanently.

#### **Combustion chamber lining**

Slight cracks can appear in the combustion chamber lining due to moisture, or to the heating/cooling process. These cracks have no influence on the heating performance or lifetime of your stove. However, if the lining starts to crumble, you must replace it. The combustion chamber lining is not covered by the warranty.

#### Gaskets

All wood-burning stoves have gaskets made of ceramic material fitted to the stove, the doors, and/or the glass. These gaskets are subject to wear and tear, and must be replaced when necessary.

## Chimney sweeping and cleaning your wood-burning stove

Follow national and local chimney sweeping regulations. We recommend having the wood-burning stove cleaned regularly by the chimney sweep.

Before starting to clean your wood-burning stove, and sweep the flue pipe, we recommend first removing the baffle plates.

#### Checking the stove

Scan A/S recommends that you check your stove thoroughly after sweeping/cleaning. Check all visible surfaces for cracks. Check that all joints are tight and that the seals sit correctly. Worn or deformed seals should be replaced.

#### Servicing

We recommend that the stove should have a comprehensive servicing at least once every two years. Servicing should include the following:

- Lubricate hinges using copper grease
- Check gaskets. Replace any that are broken or weak.
- Check combustion chamber door and riddling grate
- Check combustion chamber lining and baffle plates.
- The stove must be serviced by a qualified fitter. Use only orignal spare parts.



The glass log guard is easy to remove and can be cleaned with glass cleaner.





## Service

#### **Baffle plates**

Please be careful when dismounting the baffle plates.

Lift up the lower baffle and dismount both pins. Then pull the plate downwards and take it out.

Push the upper baffle forwards so that it is freed from the fittings at the rear of the combustion chamber. Then take out the plate.

We refer to page 13 for a detailed description of the mounting/dismounting of the burn chamber plates.





#### The door does not close

It may occur during transport that the locking device moves out if its correct position, so that the door does not close properly. This can easily be adjusted, see below.







## TROUBLESHOOTING

#### Smoke escaping

- Damp wood
- Chimney not drawing properly
- · Chimney is not properly dimensioned for the stove
- Check if the smoke gas pipe/chimney are blocked
- Is the chimney the right height for its surroundings?
- At rear outlet, check that the flue pipe does not obstruct the chimney draught
- Vacuum in room
- The door is opened before the embers have burned down sufficiently

#### Wood burning too quickly

- The air valves are set incorrectly
- · The baffle plates is incorrectly mounted or missing
- Inferior firewood (waste wood, pallets etc.)
- Chimney too large

#### Soot build-up on glass

- Incorrect secondary airflow setting
- Excessive primary air
- Damp wood
- Wood pieces too large on lighting
- · Inferior firewood (waste wood, pallets etc.)
- Chimney not drawing sufficiently
- Vacuum in room

#### Excessive soot build-up in chimney

- Poor burning (more air required)
- Damp wood

#### The surface of the stove is turning grey

• Overheating (see instructions for heating)

#### Poor heating performance of stove

- Damp wood
- Not enough wood
- Inferior wood quality with low fuel value
- · Baffle plates are not fitted correctly

#### Odour coming from stove

- The lacquer on the stove hardens when you use the stove for the first time; this can cause an odour. Open a window or a door for ventilation, and make sure the stove is heated up sufficiently to avoid odours later.
- When heating up and cooling down, the stove may make some clicking noises. These are due to the huge temperature differences to which the material is exposed and do not indicate any product defects.

#### Warranty

All wood-fired Scan products are made of high-quality materials and subject to strict quality controls before leaving the factory. We give a warranty of 5 years on manufacturing errors or defects.

You must quote your stove's product registration number when you contact us or your authorised Scan dealer with a warranty claim.

The warranty covers all parts which in the opinion of Scan A/S require repair or replacement due to manufacturing or construction error

The warranty applies to the original purchaser of the product only, and is not transferable (except on prior sale).

The warranty covers only damage caused by manufacturing or construction errors.

# The following parts are not covered by the warranty

- Wear and tear parts, such as the combustion chamber liners, baffle plates, riddling grate, glass, tiles, and seals (except for defects which were present on delivery).
- Defects caused by external chemical and physical influences during transportation, storage and assembly, or at a later time.
- Soot build-up caused by poor chimney draught, damp wood, or improper use.
- Costs of additional heating in connection with a repair.
- · Transport costs.
- Costs for setting up, removing the wood stove.

#### This warranty is void

- In case of incorrect installation (the installer is responsible for observing and complying with legal requirements and local bylaws, along with this Assembly- and Instructionsmanual for the wood-burning stove and accessories).
- In case of improper use, and/or use of prohibited fuels, nonoriginal spares (see this Assembly- and instructions manual).
- If the product registration number of the stove has been removed or damaged.
- In case of repairs that do not comply with our instructions or instructions by an authorised Scan dealer.
- In case of any manipulation of the original state of this Scan product or its accessories.
- This warranty is only valid in the country to which this Scan product was originally supplied.

Always use original replacement parts, or parts recommended by the manufacturer.

Version: UK 90066500 10056056-P01 13-01-2020

